

## EZIPRIME® ANFO primer

### RECOMMENDATION FOR USE

#### Charging with EZIPRIME®

1. Insert the detonator until it reaches the bottom of the capwell.



2. Clip the shock-tube into the retention lug



EZIPRIME®  
Shown with detonator partially inserted

3. EZIPRIME® must be forward primed in the borehole.

